



TUBOSIDER Singlestore Installation Guide

Installation

1. Bed pipe on pre-shaped bed.
2. The gaskets should be placed around the pipe ends, equally about the joint. Overlap the gasket at the crown of the pipe and fix in place with double-sided tape. Lightly grease the inside face of the coupling band with the pipe grease provided.
3. Place the bottom segment of the band with the band dimple seated into the second corrugation (**Fig.1**) of the re-rolled section of the pipe and chock in position with a timber wedge.
4. Place the next pipe so that its second re-roll corrugation sits into the band dimple. When abutting pipes a target gap of 5-15mm between the pipe ends is ideal.
5. Place the second part of the band over the pipe ensuring a good and even seating of the band dimple into the second re-roll corrugation of each pipe (**Fig.2**)
6. Locate the M12 studs provided through the lugs and place the saddle washers, loosely tighten the nuts ensuring that the curved face of the saddle washers sit into the radius of the lugs.
7. Tighten down the nuts on the studs, evenly on each lug at both sides of the pipe. If necessary "dress" the band with a small rubber mallet while tightening (**Fig.3**). Tubosider do not specify a torque for this. As a guide if the studs have started to bend then the band is sufficiently tightened.
8. Inspect internally to ensure uniform contact with the gasket, if gaskets are used.




Fig.1




Fig.2



Fig.3

It is important that the pipes are laid at a constant grade and line relative to each other. Any significant deviation from line and level will create problems in locating and tightening the coupling band. The larger the pipe diameter, the more important true line and level will be.

Where bitumen paved inverts are installed, there might be a tendency for the pipes to assume a slightly egg-shaped profile during lifting and handling. This should be monitored when the pipes are placed end to end prior to positioning the second or third segments of the coupling band.

If there is a poor match in terms of shape then the pipe ends should be jacked into shape by the use of Acrow props or similar and held in a true circular profile whilst the coupling bands are placed and tightened and if needed be left in position until backfill is placed. Generally, pipes over 1.4m diameter have match marked ends and each pipe is marked with a pipe sequence number. Pipes should be laid in this sequence to ensure good diameter match.

Please also watch How To: Lay a Singlestore Pipe and Join Two Pipes <https://tubosider.co.uk/how-to-guides/>

We recommend that the installer uses the Jointing Inspection Record sheet found on the last page of this document to provide a quality audit trail.



TUBOSIDER Singlestore Installation Guide

Handling

Although corrugated steel pipes are known for their strength, they should be handled with reasonable care. Never dumped pipes directly from a truck bed on unloading, lift in a way that protects the galvanised or coated surface. As with any manufacturer pipes should not be dragged across the site.

Tubosider pipes are relatively light in weight, typically supplied in around 7m lengths, they can be handled with simple, light equipment. In assessing handling requirements, the contractor should ascertain the heaviest part of any delivery. This information will be on the drawing or be available from Tubosider UK Ltd.

Pipes should ideally be handled with a double sling (**Fig.4**), to prevent excessive localised stresses in the pipe that could cause damage. In the case of longer pipes it may be prudent to use a spreader beam for off-loading and placing. Pipes should be handled with nylon slings and not with pipe hooks or items that can cause damage to pipe ends.

Do NOT lift with single strap or without bite. ALWAYS follow site safety procedures.

Off-Loading Guidance For safe transport and handling, Tubosider fasten pipes together

with steel banding. Packs of pipes sit on the vehicle on wooden skids to enable loading transport at the factory from a crane (**Fig.6**) or forklift truck (**Fig.7**). Skids are also used between rows of pipes (**Fig.8**). Wedges (chocks) are used to stop lateral movement of the pipes.

When off-loading a pack of pipes, nylon slings should be used if lifting by excavator or crane. Alternatively use a forklift truck or excavator with fork attachments. When the pack is placed at ground level, the banding can be removed as required and the pack split. Single pipes can then be handled with care, again using a crane with slings or forks.

Notes: The above is for guidance and should be followed in conjunction with current health & safety guidelines and site health & safety policy.

Please note that the skids on the vehicle bed can be retained for use and disposal on site. Be aware of the possibility of nails and splintering.




Fig.8



Fig.4



Fig.5



Fig.6




Fig.7



TUBOSIDER Singlestore Installation Guide

Packing for transport

These diagrams show how straight pipes are typically packed. Pipes that have additional factory fabrication work might not be packed as shown.



Weights

The tables can be used to calculate straight pipe weights. Please contact Tubosider should you require weights confirming for off-loading and handling plant on site.

Singlestore 68						
Clear Internal Diameter (m)	Weight per metre (kg)					Clear End Area (m)
	Steel thickness (mm)					
	1.5	2.0	2.5	3.0	3.5	
0.3	14	-	-	-	-	0.07
0.4	18	-	-	-	-	0.13
0.5	23	-	-	-	-	0.20
0.6	27	36	-	-	-	0.28
0.7	32	41	-	-	-	0.38
0.8	36	47	-	-	-	0.50
0.9	41	53	66	79	90	0.64
1.0	45	59	73	87	100	0.78
1.1	50	65	80	95	109	0.95
1.2	54	72	89	106	118	1.13

Indicative weights for Singlestore pipes


Singlestore 125						
Clear Internal Diameter (m)	Weight per metre (kg)					Clear End Area (m)
	Steel thickness (mm)					
	1.5	2.0	2.5	3.0	3.5	
1.2	55	73	90	108	124	1.13
1.4	65	85	105	125	145	1.54
1.5	69	91	113	134	156	1.77
1.6	74	97	120	143	166	2.01
1.8	83	109	135	161	187	2.55
2.0	92	121	150	178	207	3.14
2.2	102	133	165	196	227	3.80
2.4	-	145	179	214	248	4.52
2.6	-	-	194	231	268	5.31
2.8	-	-	209	249	289	6.16
3.0	-	-	-	267	309	7.07
3.2	-	-	-	-	329	8.04
3.4	-	-	-	-	350	9.08
3.6	-	-	-	-	371	10.18

Indicative weights for Singlestore pipes




TUBOSIDER Singlestore Installation Guide

Excavation and Backfill requirements according to CD375



Multiple Runs



Single Run

Minimum depth (X) of Lower Bedding material to be equal to Diameter (D) divided by 10. Therefore, for an 1.8m pipe, X = 180mm. For a 2.4m pipe, X = 240mm etc.

*Dimension W to be 500mm for pipes less than 3m diameter.

*Dimension W to be 800mm for pipes 3m and above.

The above information is drawn from the Design Manual for Roads And Bridges. The materials listed below are as described in Series 600 MCHW1.

Bedding and Backfill materials

Lower bedding material	6K	Natural gravel, natural sand, crushed gravel, crushed rock other than argillaceous rock, crushed concrete, well-burnt colliery spoil or any combination thereof								
Upper bedding material	6L	Natural gravel, natural sand, crushed gravel, crushed rock other than argillaceous rock, crushed concrete, well-burnt colliery spoil or any combination thereof								
Surround Material	6M	Natural gravel, natural sand, crushed gravel, crushed rock other than argillaceous rock, crushed concrete, well-burnt colliery spoil or any combination thereof								
Material	PERCENTAGE BY MASS PASSING THE SIZE SHOWN									
	Size (mm) BS Series					Size (µm) BS Series				
	75	20	10	5	2	1.18	600	300	150	63
Lower bedding 6K	100									0-10
Upper bedding 6L			100	89-100	60-100	30-100	15-100	5-70	0-15 Except 0-20 for crushed rock	
Surround 6M	100									0-10



TUBOSIDER

Singlestore Installation Guide

Backfilling Guidance

Correct placement of bedding materials, including the shaping of the bedding to support 20% of the circumference of the pipe is important. Getting this right not only gives the correct structural support to the pipes, it also ensures good line and level along the length of the tank or culvert.

The material under the haunches must be in firm contact with the entire bottom surface of the pipes, taking great care at this stage will ensure that the backfill is correctly compacted and that the layer is thick enough to spread and accommodate the high pressures that are in this area. When well compacted voids and soft spots should not occur.

As the first layer of granular fill is placed, the haunches are more accessible due to the bedding described above. Backfilling and compacting under the haunches is an important step in the backfill sequence. Hand equipment like a shovel should be used to fill the remaining haunches. Small power tampers can be used to compact with care being taken to avoid striking the structure.

When placing backfill, layers are generally put down at thicknesses of 150mm to 300mm to permit thorough compaction. A balanced sequence of backfilling is essential. The fill should be placed on both sides of the pipe at the same time, or alternating from one side to the other to keep it close to the same elevation on both sides of the pipes at all times.


When the fill on both sides of a pipe run approaches the top of the structure, the same techniques of spreading shallow layers and compacting thoroughly must be continued as the fill covers the pipe. For the initial layers over the pipe, light compaction equipment like a hand operated drum roller, working across the pipe is recommended.

Generally, on reaching 1 metre of cover above soffit level, in compacted layers, suitable larger plant may be used. Please contact Tubosider to discuss construction loadings, especially under reduced cover.



TUBOSIDER Singlestore Installation Guide

Typical Access shaft finishing detail



Notes:

1. When calculating access shaft heights Tubosider allow 500mm between finished cover level (FCL) and top of shaft.
2. The 500mm is typically made up of a concrete "biscuit", 2 courses of bricks and a steel manhole frame. Any discrepancy can be taken up within the brickwork.
3. Prior to placing the "biscuit" the top of the shaft should be wrapped with Denzo or polystyrene and the concrete ring should be cast with the top approx. 50mm above the top of the shaft. The "biscuit" should then be bedded onto the concrete ring with sand and cement mortar.
4. Concrete "biscuit", bricks, cover and frame supplied by others.

Fixing the eyebolt, if required

TOOLING

Use hammer drill and sds drill bit.

Drill bit diameter: Ensure correct diameter is selected for the fixing to be used and is not worn below minimum tolerance.

NB. When drilling into dense concrete observe the maximum efficient working life of the drill bit.

PREPARATION

Hole depth must be 2 times diameter plus the full working length of the bolt, to allow for the dust created when the bolt is installed into the pre-drilled hole.

Remove surplus dust from the drilled hole by easing the drill bit up and down within the hole and blowing clear.

INSTALLATION


To install the screwbolt use a branded ratchet spanner with a full hexagon socket, or impact wrench. We recommend the use of the bosch gds or similar. To ensure that you do not ream out the drilled hole set the impact wrench to slow start.

This will also avoid any excessive torque stress being applied to the bolt.

Apply pressure to head of bolt to ensure engagement of first thread.

If resistance is encountered when screwing down the bolt, simply unscrew one turn to release trapped dust, and then continue to tighten down. The bolt is set when the built in washer, at the underside of the head of the bolt, meets the face of the object being fixed to the substrate.

No further tightening of the fixing is necessary.



© Excalibur Screwbolts_November 2009



TUBOSIDER Singlestore Installation Guide

Storm Water Retention Tanks Singlestore Jointing Self Inspection Record

Joint Number	Pipe Number	Gasket Condition OK	Grease Used	Uniform Gap between joints	Bolts sufficiently tightened	Installer Initials	Date
--------------	-------------	---------------------	-------------	----------------------------	------------------------------	--------------------	------

Installer Signature:

Customer Signature:

Installer Name (Print):

Customer Name (Print):

Page No: <input type="text"/>	of	<input type="text"/>
-------------------------------	----	----------------------

Please return this installation inspection record to Tubosider UK Ltd within 14 days of final joint installation. A copy of this will be returned to you with an O&M manual on request. Failure to return all or any part of this inspection record may void any warranties.